

Left Audio Monitor/Speaker				PRODUCTION								Right Audio Monitor/Speaker			
				A: 1025 (Preview DA)		A: 631 (Router)		A: 1137 LP 1141	A: 1138 LP 1142	A: 1119	A: 1120				
<b>59</b> Chy-1	<b>60a</b> Chy-2	<b>60b</b> DVE	<b>60c</b> Patch	<b>63</b> <b>PRE</b>		<b>73</b> <b>PGM</b>		<b>87</b>	<b>88</b>	<b>97</b>	<b>98</b>				
<b>55</b> SS-in	<b>56</b> SS-edit	<b>57</b> SS-air	<b>58</b> SS-Pre					B: Still Store 1	B: Still Store 2	(No Tally)	(No Tally)				
A: 842 (ME1)		A: 843 (ME2)						A: 943 LP 923	A: 945 LP 947	A: 1117	A: 1118				
<b>53</b>		<b>54</b>						Chyron 1	Chyron 2	(No Tally)	(No Tally)				
B: 937 (A51 ChA)		B: 938 (A51 ChB)		B: 1026 (Program DA)		B: 1028 (Preview DA)									
A: 1125 A51 Menu		A: 1126 A51 Inputs		A: 1129	A: 1130	A: 1133	A: 1134	A: 1115 LP 1015	A: 1116 LP 1039	A: 944 LP 918	A: 946 LP 942		B&W Monitors are below this line		
<b>51</b>		<b>52</b>		<b>64</b>	<b>65</b>	<b>74</b>	<b>75</b>	<b>83</b>	<b>84</b>	<b>93</b>	<b>94</b>				
B: 845		B: 846 A51 out		Cam 1	Cam 2	Cam 3	Cam 4	Cam 5	Cam 6						
Feral Effects Unit				A: 1127	A: 1128	A: 1131	A: 1132	A: 1135 LP 1003	A: 1027 LP 1136	A: 1139 LP 1143	A: 1140 LP 1144				
Abekas A51+ DVE Control Panel				<b>61</b>	<b>62</b>	<b>71</b>	<b>72</b>	<b>81</b>	<b>82</b>	<b>91</b>	<b>92</b>				
				Cam 1	Cam 2	Cam 3	Cam 4	Cam 5	Cam 6						
				TD's RTS station				Director's RTS & IFB		Assist. Director's RTS & IFB					

Color Monitors  
are above  
this line

B&W Monitors  
are below  
this line

VIDEO TAPE MONITORS					
4" Color LCD's					
34a <b>CAM-1</b>	34b <b>CAM-2</b>	34c <b>CAM-3</b>	34d <b>CAM-4</b>		
33a <b>CAM-5</b>	33b <b>CAM-6</b>	33c <b>PP 124</b>	33d <b>Scope</b>		
8" Color (Lower Monitors)					
A:925 LP 125 VT-1 <b>21</b>	A:927 LP 127 VT-7 <b>22</b>	A:929 LP 129 VT-2 <b>31</b>	A:931 LP 131 VT-8 <b>32</b>	A:933 LP 133 Whip <b>41</b>	A:935 LP 111 VT-6 <b>42</b>
B:926 LP 126 VT-4	B:928 LP 128 TBC1	B:930 LP 130 VT-5	B:932 LP 132 Tuner	B:934 LP 134 VT-9	B:936 LP 112

AUDIO MONITORS					
8" Color		10" LCD			
A: 632 <b>131</b>	A: 633 <b>132</b>	<b>PGM</b>			
Router 1		Router 2		Program	
4" Color LCD's					
		Mon 134	Mon 141	Mon 142	
<b>Cam 1</b>	<b>Cam 2</b>	<b>Cam 3</b>	<b>Cam 4</b>	<b>Cam 5</b>	<b>Cam 6</b>
B: N/C	B: N/C	B: N/C	B: 1016	B: 1040	B: 1017

CHYRON - BACK BENCH				
A: 1004 <b>101</b>	A: 1030 Program <b>102</b>	A: 1146 Chy Menu <b>103</b>	A: 1032 Chy 1 Edit <b>104</b>	A: 1034 Chy 2 Edit <b>105</b>
B: 1029	B: 1031	B: 1145	B: 1033	B: 1035

## MAGNETIC IMAGE VIDEO SPOTLITE PRODUCTIONS MONITOR WALL CHART